



Boot Mode Configuration

Pin	Run	Bootloader	Default
IO0	1	0	1
IO2	x	0	0
IO5	1	x	0
IO12	0	0	0
IO15	x	x	1

IO12 = MDTI, IO15 = MDT0

If DTR is LOW, toggling RTS from HIGH to LOW resets to run mode.
If RTS is HIGH, toggling DTR from LOW to HIGH resets to bootloader.



Released under the Creative Commons Attribution Share-Alike 4.0 License
https://creativecommons.org/licenses/by-sa/4.0/

Special Instructions

TITLE: SparkFun_IoT_RedBoard-ESP32

Design by: Ricardo Ramos
Revised by: Dryw Wade T.igoe, G.Martino, D.Mellis

Based on Arduino by M.Banzi, D.Cuarterles,
v10

Date: 8/11/2022 9:48 AM

Sheet: 1/1