


Intel[®] Edison Pinout



(Bottom view)

VSYS	2.	1.	GND
VSYS	4.	3.	USB_ID
VSYS	6.	5.	GND
3.3V	8.	7.	MSIC_SLP_CLK3
3.3V	10.	9.	GND
1.8V	12.	11.	GND
DCIN	14.	13.	GND
USB_DP	16.	15.	GND
USB_DN	18.	17.	PWRBTN#
USB_VBUS	20.	19.	FAULT
GP134/UART_2_RX	22.	21.	PSW
GP44	24.	23.	V_VBAT_BKP
GP45	26.	25.	GP165
GP46	28.	27.	GP135/UART_2_TX
GP47	30.	29.	NC
GP48	32.	31.	RCVR_MODE
GP49	34.	33.	GP13/PWM_1
RESET_OUT#	36.	35.	GP12/PWM_0
NC	38.	37.	GP182/PWM_2
NC	40.	39.	GP183/PWM_3
GP15	42.	41.	GP19/I2C_1_SCL
GP84/SD_0_CLK_FB	44.	43.	GP20/I2C_1_SDA
GP131/UART_1_TX	46.	45.	GP27/I2C_6_SCL
GP14	48.	47.	GP28/I2C_6_SDA
GP42/I2S_2_RXD	50.	49.	NC
GP40/I2S_2_CLK	52.	51.	GP111/SPI_2_FS1
GP41/I2S_2_FS	54.	53.	GP110/SPI_2_FS0
GP43/I2S_2_TXD	56.	55.	GP109/SPI_2_CLK
GP78/SD_0_CLK	58.	57.	GP115/SPI_2_TXD
GP77/SD_0_CD#	60.	59.	GP114/SPI_2_RXD
GP79/SD_0_CMD	62.	61.	GP130/UART_1_RX
GP82/SD_0_DAT2	64.	63.	GP129/UART_1_RTS
GP80/SD_0_DAT0	66.	65.	GP128/UART_1_CTS
GP83/SD_0_DAT3	68.	67.	OSC_CLK_OUT_0
GP81/SD_0_DAT1	70.	69.	FW_RCVR