

Automatic Can Crusher Code:

Inputs

- 0 - Key Switch
- 1 - Start (big red center button)
- 2 - Stop Switch
- 3 - On/Off Switch
- 4 - Proxy Sensor

Outputs

- Solenoid 1 - Main Push
- Solenoid 2 - Main Pull
- Solenoid 3 - Turn 1
- Solenoid 4 - Turn 2

- 20 -- Green LED
- 21 -- Orange LED
- 22 -- Red LED

The key must be ON to use the crusher

The stop switch should toggle a relay On and Off to pause operations, it should also make all of the LEDs flash rapidly

The proxy switch toggles the crusher into a ready/not ready state (green and red LED) if the On/off switch is ON

If the crusher is in a ready state, the big red switch will activate the crusher, turning the orange LED on

MODE 1 - Sensor Switch is in the ON position

[STOP SWITCH TOGGLE]

STR 02
AND NOT 161
OUT 160

STR 02
OUT 161

STR 160
AND 20
OUT 162

STR 160
OR 20
AND NOT 162
OUT **140** <----- Coil 140 is the stop switch on/off

STR 140 -- [E-STOP ON]
OR NOT 004 -- [NO CAN BY PROXY]
AND 003 -- [SENSOR SWITCH ON]
OUT 022 -- [RED LED ON]

STR 004 -- [CAN BY PROXY]
AND 003 -- [SENSORS ON]
AND NOT 140 -- [E-STOP OFF]
OUT 020 -- [GREEN LED ON]

[START CRUSHER TOGGLE]

STR 00
AND NOT 164
OUT 163

STR 02
OUT 164

STR 163
AND 20
OUT 165

STR 163
OR 20
AND NOT 165
OUT **141** <----- Coil 141 is the big red switch on/off

[THE ACTUAL CRUSHING]

STR 141 -- [BIG RED SWITCH PRESSED]
AND 000 -- [KEY ON]
AND NOT 140 -- [E-STOP SWITCH OFF]
AND 004 -- [PROXY CLOSED]
AND 003 -- [SENSORS ON]
OUT **142 -- [START CRUSHING SEQUENCE]**

STR 142
AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
SET 300
OUT 21 -- [ORANGE LED ON]

STR 300 **[DROPS CAN TO BE CRUSHED, RELOADS]**
AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
TMR 600
=2.0
OUT 21 -- [ORANGE LED ON]

STR NOT TMR 600
AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
OUT #3 -- [DROP CAN INTO CRUSHER]
SET 301
OUT 21 -- [ORANGE LED ON]

STR TMR 600

AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
OUT #4 -- [LOAD CAN CHUTE]
OUT 21 -- [ORANGE LED ON]

STR 301
AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
TMR 601
=2.0
OUT 21 -- [ORANGE LED ON]

[CRUSHES CAN, RETRACTS]

STR NOT TMR 601
AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
OUT #1 -- [MAIN EXTEND]
OUT 21 -- [ORANGE LED ON]

STR TMR 601
AND NOT 140 -- [E-STOP OFF]
AND 000 -- [KEY ON]
OUT #2 -- [MAIN RETRACT]
OUT 21 -- [ORANGE LED ON]
RST 300
RST 301
