

Nordic Thingy:91

User Guide

v1.3



NORDIC[®]
SEMICONDUCTOR

Contents

| | | |
|----------|--|-----------|
| | Revision history | iv |
| 1 | Introduction. | 5 |
| 2 | Related documentation. | 7 |
| 3 | Kit content. | 8 |
| | 3.1 Downloadable content | 8 |
| 4 | Getting started. | 10 |
| | 4.1 Connecting LTE Link Monitor | 12 |
| 5 | Firmware. | 13 |
| | 5.1 Programming Nordic Thingy:91 | 13 |
| 6 | Hardware description. | 14 |
| | 6.1 Block diagram | 14 |
| | 6.2 Hardware figures | 14 |
| | 6.3 nRF9160 | 15 |
| | 6.3.1 Antenna tuning | 16 |
| | 6.3.2 RF measurements | 17 |
| | 6.3.3 GPS | 17 |
| | 6.3.4 SIM card | 18 |
| | 6.4 nRF52840 | 19 |
| | 6.4.1 NFC passive tag | 19 |
| | 6.4.2 USB | 20 |
| | 6.5 Pin maps | 20 |
| | 6.6 Motion sensors | 23 |
| | 6.7 Environment sensors | 25 |
| | 6.8 Buzzer | 25 |
| | 6.9 LEDs and buttons | 26 |
| | 6.9.1 RGB LED | 26 |
| | 6.9.2 Buttons | 26 |
| | 6.10 Power supply | 26 |
| | 6.10.1 PMIC | 27 |
| | 6.10.2 Current measurement | 27 |
| | 6.11 Programming and debugging interface | 28 |
| | 6.12 Interface | 29 |
| | 6.12.1 N-MOS transistors | 29 |
| | 6.12.2 Connectors | 30 |
| | 6.12.3 Test points | 31 |
| 7 | Regulatory notices. | 34 |
| | 7.1 FCC regulatory notices | 34 |
| | Glossary | 35 |
| | Acronyms and abbreviations. | 37 |

| | |
|------------------------|----|
| Legal notices. | 38 |
|------------------------|----|

Revision history

| Date | Version | Description |
|---------------|---------|--|
| May 2020 | 1.3 | Updated: <ul style="list-style-type: none">• Firmware on page 13 by adding links to relevant documentation Replaced: <ul style="list-style-type: none">• Firmware update chapter with Programming Nordic Thingy:91 on page 13 |
| April 2020 | 1.2 | Updated Introduction on page 5 |
| December 2019 | 1.1 | Updated: <ul style="list-style-type: none">• Kit content diagram and added a short description• Getting started on page 10• Connecting LTE Link Monitor on page 12• Buttons on page 26• Figures with callouts indicating functionality of components Added the different ways to obtain firmware images for updating firmware, and operating modes: <ul style="list-style-type: none">• Firmware on page 13 Updated different firmware update methods and added new update technique using USB (MCUBoot) |
| August 2019 | 1.0 | First release |

1 Introduction

The Nordic Thingy:91™ is a battery-operated prototyping platform for cellular IoT, certified for global operation. It is ideal for rapid development of prototypes for cellular IoT systems and is especially suited for asset tracking applications and environmental monitoring.

Nordic Thingy:91 includes sensors that gather data about its own movements and the surrounding environment. Temperature, humidity, air quality, air pressure, color, and light data can easily be extracted for local or remote analysis. For input, the Nordic Thingy:91 offers a user-programmable button. Visual output is achieved with RGB indicator LEDs, while a buzzer can provide audible output. The standard application firmware on Nordic Thingy:91 extracts the data from the different sensors and relays it securely to the nRF Connect for Cloud, where it is displayed in a user-friendly interface.

The firmware supports concurrent operation with LTE Link Monitor, a tool providing an AT command interface, enabling link and network testing. LTE Link Monitor is an application, which is implemented as part of the nRF Connect for Desktop application. The firmware has been developed using the nRF Connect *Software Development Kit (SDK)*. It is open source and can be leveraged and modified to suit your specific needs. The firmware can be updated and debugged by using an external programmer/debug probe, for example nRF9160 *Development Kit (DK)* or J-Link device supporting Arm Cortex-M33.

Nordic Thingy:91 integrates the nRF9160 *System in Package (SiP)*¹, supporting LTE-M, NB-IoT and *Global Positioning System (GPS)*, and the nRF52840 *System on Chip (SoC)*, supporting *Bluetooth®* Low Energy and *Near Field Communication (NFC)* passive tag.

Note: LTE-M or LTE NB-IoT can operate simultaneously with Bluetooth LE.

Source code for firmware, hardware layout, and schematics are all available on our web site www.nordicsemi.com.

Nordic Thingy:91 has an antenna supporting *GPS*, LTE-M, and NB-IoT that enables it to support a global range of LTE bands. It has two antennas connected to the nRF52840: a 2.4 GHz antenna for Bluetooth LE and an *NFC* passive tag antenna. To connect to cellular network out of the box, Nordic Thingy:91 has a nano/4FF SIM card slot and is bundled with a SIM card from iBasis that comes preloaded with 10 MB.

NFC in Nordic Thingy:91 operates as a passive tag (e.g. it does not feature a reader function). Nordic Thingy:91 may use this tag function for the Out of Band pairing feature as described in the Bluetooth Core Specification.

A 1400 mAh rechargeable Li-Po battery is also part of this prototyping platform giving a smooth transition into prototype field-testing.

Key features of Nordic Thingy:91

- 700-960 MHz + 1710-2200 MHz LTE band support². The following bands, based on geographic regions, are used:
 - USA – 2, 4, 12, and 13
 - EU – 3, 8, 20, and 28
- Certifications: CE, FCC
- LTE-M/NB-IoT/*GPS*, Bluetooth LE and *NFC* passive tag antennas

¹ The nRF9160 *SiP* is certified for USA bands 2, 4, 5, 12, 13, 14, 17, 25, 26, and 66. However, Nordic Thingy:91 operates and is only certified for USA bands 2, 4, 12, and 13. The Nordic Thingy:91 firmware is written and documented to only use this subset of USA bands.

² The application currently enables the following frequency bands: 2, 3, 4, 8, 12, 13, 20, and 28.

- Nano/4FF *Subscriber Identity Module (SIM)* card slot
- User-programmable button and RGB LEDs
- Environmental sensor for temperature, humidity, air quality, and air pressure
- Color and light sensor
- Low-power and high-G accelerometer
- Buzzer
- 4 x N-MOS transistor for external DC motors or LEDs
- Rechargeable Li-Po battery with 1400 mAh capacity
- Charging through *Universal Serial Bus (USB)*
- PC connection through *USB*
- Normal operating temperature range: 5°C ~ 35°C

nRF9160

- Multimode LTE-M/NB-IoT modem
 - GCF certified for global operation
 - 23 dBm output power
 - *GPS*
 - Power saving features: DRX, eDRX, PSM
 - Coverage enhancement modes
 - Single pin 50 Ω antenna interface
 - *Universal Integrated Circuit Card (UICC)* interface
- Application processor
 - 64 MHz Arm® Cortex®-M33 CPU
 - Arm TrustZone® for trusted execution
 - Arm CryptoCell 310 for application layer security
 - 1 MB flash and 256 kB RAM
 - 4 x SPI/UART/TWI, PDM, I2S, PWM, ADC

nRF52840 WLCSP

- Bluetooth LE and *NFC* passive tag support
- 64 MHz Arm Cortex-M4F CPU
- 1 MB flash and 256 kB RAM
- *USB*



Environmental Protection

Waste electrical products should not be disposed of with household waste.

Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.



廢電池請回收

The battery in this product cannot be easily replaced by users themselves. Batteries should be removed only by qualified professionals due to safety concerns.

2 Related documentation

In addition to the information in this document, you may need to consult other Nordic documents.

- [nRF9160 Product Specification](#)
- [nRF52840 Product Specification](#)
- [nRF9160 DK](#)
- [nRF52840 DK](#)
- [nRF9160 Errata](#)
- [nRF52840 Errata](#)
- [nRF Connect SDK documentation](#)
- [nRF Connect for Cloud](#)
- [nRF Connect LTE Link Monitor](#)
- [nRF Connect Programmer](#)
- [nRF91 AT Commands Reference Guide](#)

3 Kit content

The Nordic Thingy:91 kit consists of hardware and access to software components, hardware design files, applications, and documentation.



Figure 1: Nordic Thingy:91 hardware content

The Nordic Thingy:91 kit contains the following:

- Nordic Thingy:91 device with a rubber enclosure serving as a protective cover
- An eSIM (SIM card) from iBASIS supported by the nano/4FF SIM card slot of Nordic Thingy:91
- An information leaflet

WARNING - Power adapter is not included in the kit.³

3.1 Downloadable content

The Nordic Thingy:91 prototyping platform includes firmware source code, documentation, hardware schematics, and layout files.

Firmware

- [Application firmware for Nordic Thingy:91](#)

³ Power supply adapter is not included in the safety certification test report, see separate test report according to IEC 62368. The power supply adapter you will use shall meet PS1 requirements.

- Precompiled HEX files
- nRF52840 *USB* to UART bridge
- [nRF9160 modem firmware](#)
- [nRF Connect SDK](#)

PC tools

- [nRF Connect LTE Link Monitor](#)
- [Segger Embedded Studio](#)
- [nRF Connect Programmer](#)

Web applications

- [nRF Connect for Cloud](#)

Hardware files

The hardware files can be downloaded from the [Nordic Thingy:91 product page](#).

The zip file and its subdirectories contain the hardware design files for the Nordic Thingy:91. The hardware files for the circuit board are available in the following folder in the hardware files zip package:

```
\Thingy91 - Hardware files x_x_x\PCA20035-Thingy91 Board x_x_x
```

In this folder, you can find the following hardware design files:

- Altium Designer files
- Schematics and PCB layout files in PDF format
- Bill of materials
- Production files:
 - Drill files
 - Assembly drawings
 - Gerber files
 - Pick-and-place files

4 Getting started

Setting up Nordic Thingy:91 requires completing the following steps.

Before you start:

- Unpack Nordic Thingy:91.
- Make sure to update the Nordic Thingy:91 firmware as explained in [Programming Nordic Thingy:91](#).
- Make sure you have an nRF Connect for Cloud account and sign in to [nRF Connect for Cloud](#).

Once you are signed in, perform the following steps.

1. Add new LTE device.




Figure 2: Adding new LTE device in nRF Cloud

2. Verify and activate the SIM card.

Input SIM ICCID and Personal Unblocking Key (PUK) from the SIM card, and add personal information.




Figure 3: Placement of PUK and SIM ICCID on the SIM card

3. Gently remove the rubber overlay to reveal the power switch and the top of Nordic Thingy:91. Insert the SIM card.




Figure 4: Inserting the SIM card

- Once the SIM card is inserted, power on Nordic Thingy:91. You will find the power switch next to the micro-USB port.




Figure 5: Nordic Thingy:91 Power switch

Wait for yellow breathing in the indicator LED. If the LED does not turn yellow, check [Operating states of Nordic Thingy:91](#) to determine the present state of Nordic Thingy:91.

- Associate the Nordic Thingy:91 to your user account.

Enter the IMEI and PIN information that is found on the sticker on the Nordic Thingy:91 PCB. Wait for blue breathing which means that your Nordic Thingy:91 is associated and connected.

Add LTE Device

To connect your device, enter the IMEI and PIN or HWID

IMEI

PIN/HWID

Add Device

[Have an old devkit without a PIN?](#)

Figure 6: Associating Nordic Thingy:91 to nRF Cloud

6. For optional activation of *GPS*, go outdoors and press the **SW3** button for a minimum of 10 seconds until the indicator LED begins breathing purple.
 - Purple breathing: *GPS* is active and searching
 - Green breathing: *GPS* has fix

Wait for green breathing in the indicator LED which indicates that your Nordic Thingy:91 has *GPS* fix.

Check that the position data and the environment sensor data are sent to nRF Connect for Cloud.

4.1 Connecting LTE Link Monitor

To get debug output and to send AT commands directly to the modem, you can connect to the Nordic Thingy:91 using nRF Connect LTE Link Monitor.

Before you begin, install and open nRF Connect for Desktop. To download the latest version, go to [nRF Connect for Desktop](#). For instructions, see [nRF Connect LTE Link Monitor](#).

To connect to the Nordic Thingy:91 using LTE Link Monitor, perform the following steps.

1. Install and launch LTE Link Monitor.
2. Connect your Nordic Thingy:91 to your computer with a *USB* cable.
3. Make sure that Nordic Thingy:91 is powered on.
4. Click **Select device** and select the device entry from the drop-down list in the LTE Link Monitor.
5. Verify the connection to the Nordic Thingy:91 modem by sending the command `AT` to the modem from the LTE Link Monitor terminal and observing that the modem responds with `OK`.

All asset tracker debug output shows up in the terminal view, and you can send AT commands to the modem to try out different settings. For further details on available AT commands, see [nRF91 AT Commands Reference Guide](#).

5 Firmware

The firmware of Nordic Thingy:91 has been developed using the nRF Connect *SDK*. It is open source, and can be modified according to specific needs.

The asset tracker application firmware, which is pre-loaded in the Nordic Thingy:91, enables the device to use the environment sensors as described in [Environment sensors](#) on page 25, and provides an option of tracking the device using GPS. The data, along with information about the device, is transmitted to Nordic Semiconductor's cloud solution, nRF Cloud, where it can be visualized. For more information on the asset tracker application, see [nRF9160 Asset Tracker](#).

You can find more information on the firmware and the associated features in the [Working with Thingy:91](#) nRF Connect *SDK* documentation.

5.1 Programming Nordic Thingy:91

You can program the modem and applications on a Nordic Thingy:91 using multiple methods. Applications can be programmed either on the nRF9160 *SiP* or on the nRF52840 *SoC*.

The different ways to program the modem and the applications on a Nordic Thingy:91 are listed below.

- Using USB (MCUboot)
- Using an external debug probe

If you are programming applications using USB, you can choose the component to be programmed by pushing the **SW3** or **SW4** button of a Nordic Thingy:91 while powering on. This puts the device in serial recovery mode.

If you are programming applications using an external debug probe, you can use an nRF9160 *DK* or any J-Link device supporting Arm Cortex-M33 as the external debug probe. The component to be programmed is determined by the setting of the **SWD** selection switch (**SW2**) of Nordic Thingy:91 to **nRF91** or **nRF52**.

See the following documentation for the detailed procedures to program applications and to program the modem on a Nordic Thingy:91.

- [Programming applications on Nordic Thingy:91](#)
- [Programming the Nordic Thingy:91 modem](#)

6 Hardware description

This chapter focuses on the hardware components of Nordic Thingy:91 with detailed descriptions of the various hardware blocks that are present on the device.

The sensors available in Nordic Thingy:91 are not calibrated in production. Nordic Semiconductor does not specify the accuracy of measurements. Users who want to reuse parts of this design to create measurement devices should conform to documentation of the specific sensors.

6.1 Block diagram

The block diagram represents interactions between hardware components on Nordic Thingy:91.




Figure 7: Nordic Thingy:91 hardware block diagram

6.2 Hardware figures

The hardware figures show elements on both sides of the Nordic Thingy:91 PCB.





Figure 8: Nordic Thingy:91 PCB, top






Figure 10: nRF9160 schematic

6.3.1 Antenna tuning

To improve antenna efficiency, Nordic Thingy:91 has dynamic antenna tuning.

Different tuning components are used for different frequencies. This is achieved by using tuning components between two SP8T RF switches. The switches are automatically controlled by the nRF9160 LTE modem and set to the correct state based on the frequency of operation. Six paths are used for LTE frequency, and one path is used for *GPS* frequency.

| RF_SW3 | RF_SW2 | RF_SW1 | State | Band | Frequency |
|--------|--------|--------|-----------|---|--|
| 0 | 0 | 0 | RF2 - RFC | Not used | Not used |
| 0 | 0 | 1 | RF7 - RFC | 13U/D, 28D | 746 MHz - 803 MHz |
| 0 | 1 | 0 | RF5 - RFC | 12U/D, 17U/D, 28U 1U/D, 2U/D, 3U/D, 4U/D, 25U/D | 698 MHz - 748 MHz 1710 MHz - 2200 MHz |
| 0 | 1 | 1 | RF3 - RFC | 5D, 20U, 26D | 824 MHz - 894 MHz |
| 1 | 0 | 0 | RF1 - RFC | 8U/D | 880 MHz - 960 MHz |
| 1 | 0 | 1 | RF8 - RFC | 5U, 20D, 26U | 791 MHz - 849 MHz |
| 1 | 1 | 0 | RF6 - RFC | Not used | Not used |
| 1 | 1 | 1 | RF4 - RFC | GPS | 1574 MHz - 1577 MHz |

Table 1: Antenna tuning bands




Figure 11: Antenna tuning circuitry schematic

6.3.2 RF measurements

The LTE signals are propagated through a coaxial connector. This makes it possible to perform conducted measurements or attach external antennas.

By default, when no cable is attached, the RF signal is routed to the onboard antenna. When connecting the adapter, the internal switch in the SWF connector will disconnect the onboard antenna and connect the RF signal from the nRF9160 to the adapter.

The connector is of SWF type (Murata part no. MM8130-2600) with an internal switch. An adapter is available (Murata part no. MXHS83QE3000) with a standard SMA connection on the other end for connecting instruments. The adapter is not included in the kit. The insertion loss in the adapter cable is approximately 0.5–1 dB.




Figure 12: Connecting a spectrum analyzer

6.3.3 GPS

The nRF9160 has a dedicated *GPS* port to support global navigation, and the same antenna is used for both LTE and *GPS*. The *GPS* signal is RX only, and there is a low-noise amplifier (LNA) that amplifies the signal before it is fed to the *GPS* RF port on the nRF9160.

The *GPS* signals are propagated through a coaxial connector located between the antenna and the LNA. This makes it possible to attach external antennas. The connector is of SWF type (Murata part no. MM8130-2600) with an internal switch. An adapter is available (Murata part no. MXHS83QE3000) with a standard SMA connection on the other end for connecting instruments. The adapter is not included in the kit. The insertion loss in the adapter cable is approximately 0.5–1 dB.




Figure 13: External GPS antenna connector

The LNA enable signal is controlled by the logic circuitry. It is enabled only when the antenna tuning circuitry is set to operate at the GPS frequency band. The LNA makes the GPS receiver more sensitive to GPS signals and less sensitive to interference from other sources nearby.




Figure 14: GPS circuit schematic

Note: GPS signals do not usually penetrate ceilings or other structures. For best GPS performance, Nordic Thingy:91 should be used outside in an open space, far from sources of interference and other structures that may block the signals.

6.3.4 SIM card

Nordic Thingy:91 is equipped with a nano-SIM (4FF) card slot.



For *USB*, *Bluetooth*, and *NFC* passive tag connectivity, Nordic Thingy:91 uses a nRF52840 SoC. It is a powerful, highly flexible, ultra-low power SoC that incorporates a Bluetooth Low Energy radio and a 32-bit Arm Cortex-M4F CPU.



Nordic Thingy:91 supports an *NFC* passive tag. *NFC*-A listen mode operation is supported on the nRF52840.




Figure 17: NFC passive tag antenna connector

The *NFC* passive tag uses two pins, **F1** (NFC1) and **E2** (NFC2), to connect the antenna. These pins are shared with *GPIOs* (**P0.09** and **P0.10**), and the **PROTECT** field in the **NFCPINS** register in **UICR** defines the usage of these pins and their protection level against abnormal voltages. The content of the **NFCPINS** register is reloaded at every reset.

Note: The *NFC* passive tag pins are enabled by default.

The *NFC* passive tag can be disabled and the *GPIOs* enabled by defining the **CONFIG_NFCT_PINS_AS_GPIO** variable in the project settings. The way of doing this depends on the *Integrated Development Environment (IDE)* or toolchain in use.

- When using SEGGER Embedded Studio, go to **Project > Edit Options > Code > Preprocessor > Preprocessor Definitions** and add the **CONFIG_NFCT_PINS_AS_GPIO** variable.
- When using Keil, go to **Project > Options for Target > C/C++ > Preprocessor Symbols > Define** and add the **CONFIG_NFCT_PINS_AS_GPIO** variable.

6.4.2 USB

The Nordic Thingy:91 *USB* connector is connected to the *USB* interface of the nRF52840 *SoC*. This enables PC communication and battery charging.

6.5 Pin maps

The pin assignments for the nRF9160 *SiP* and nRF52840 *SoC* are listed in the pin map tables.

| I/O | Label | Description |
|-------|-----------------|---|
| P0.00 | SENSE_LED_RED | Red color of the color sensor support LED |
| P0.01 | SENSE_LED_GREEN | Green color of the color sensor support LED |
| P0.02 | SENSE_LED_BLUE | Blue color of the color sensor support LED |
| P0.03 | SCK | SPI clock line |
| P0.04 | MOSI | SPI master output, slave input data line |
| P0.05 | MISO | SPI master input, slave output data line |
| P0.06 | ADXL372_INT1 | High-G accelerometer interrupt line |
| P0.07 | ADXL372_CS | High-G accelerometer chip select line |

| I/O | Label | Description |
|-------|-----------------|---|
| P0.08 | ADXL362_CS | Low-power accelerometer chip select line |
| P0.09 | ADXL362_INT1 | Low-power accelerometer interrupt line |
| P0.10 | ADXL362_INT2 | Accelerometer interrupt line 2, selectable by solder bridge |
| P0.11 | SDA | I ² C data line |
| P0.12 | SCL | I ² C clock line |
| P0.13 | N-MOS_1 | Gate of N-MOS transistor externally available |
| P0.14 | N-MOS_2 | Gate of N-MOS transistor externally available |
| P0.15 | N-MOS_3 | Gate of N-MOS transistor externally available |
| P0.16 | N-MOS_4 | Gate of N-MOS transistor externally available |
| P0.17 | ADP_INT | PMIC interrupt line |
| P0.18 | MCU_IF0 | nRF52840 interface |
| P0.19 | MCU_IF1 | nRF52840 interface |
| P0.20 | MCU_IF2 | nRF52840 interface |
| P0.21 | MCU_IF3 | nRF52840 interface |
| P0.22 | MCU_IF4 | nRF52840 interface |
| P0.23 | MCU_IF5 | nRF52840 interface |
| P0.24 | MCU_IF6 | nRF52840 interface |
| P0.25 | MCU_IF7 | nRF52840 interface |
| P0.26 | BUTTON | Button input |
| P0.27 | BH_INT | Color sensor interrupt line |
| P0.28 | BUZZER | Buzzer PWM signal |
| P0.29 | LIGHTWELL_RED | Red color of the lightwell LEDs |
| P0.30 | LIGHTWELL_GREEN | Green color of the lightwell LEDs |
| P0.31 | LIGHTWELL_BLUE | Blue color of the lightwell LEDs |

Table 2: nRF9160 pin map

| I/O | Label | Description |
|-------|-------------|---|
| P0.00 | XL1 | Low frequency crystal |
| P0.01 | XL2 | Low frequency crystal |
| P0.02 | N.A. | Not used |
| P0.03 | SPARE7 | Analog/digital <i>GPIO</i> externally available |
| P0.04 | N.A. | Not used |
| P0.05 | SPARE2 | Analog/digital <i>GPIO</i> externally available |
| P0.06 | SPARE1 | Digital <i>GPIO</i> externally available |
| P0.07 | N.A. | Not used |
| P0.08 | N.A. | Not used |
| P0.09 | NFC1 | <i>NFC</i> passive tag antenna |
| P0.10 | NFC2 | <i>NFC</i> passive tag antenna |
| P0.11 | MCU_IF0 | nRF9160 interface |
| P0.12 | N.A. | Not used |
| P0.13 | N.A. | Not used |
| P0.14 | IF_SWD_IO | nRF9160 SWD interface data line |
| P0.15 | MCU_IF1 | nRF9160 interface |
| P0.16 | N.A. | Not used |
| P0.17 | IF_SWD_CTRL | nRF9160 SWD interface control |
| P0.18 | RESET | nRF52840 reset line, available on test point |
| P0.19 | MCU_IF6 | nRF9160 interface |
| P0.20 | MCU_IF2 | nRF9160 interface |
| P0.21 | MCU_IF3 | nRF9160 interface |
| P0.22 | MCU_IF7 | nRF9160 interface |
| P0.23 | N.A. | Not used |
| P0.24 | N.A. | Not used |
| P0.25 | MCU_IF5 | nRF9160 interface |
| P0.26 | SPARE3 | Digital <i>GPIO</i> externally available |
| P0.27 | SPARE4 | Digital <i>GPIO</i> externally available |
| P0.28 | SPARE5 | Digital <i>GPIO</i> externally available |
| P0.29 | N.A. | Not used |
| P0.30 | SPARE6 | Analog/digital <i>GPIO</i> externally available |
| P0.31 | N.A. | Not used |
| P1.00 | MCU_IF4 | nRF9160 interface |
| P1.01 | COEX2 | nRF9160 COEX interface |

| I/O | Label | Description |
|-------|------------|--|
| P1.02 | N.A. | Not used |
| P1.03 | N.A. | Not used |
| P1.04 | COEX1 | nRF9160 COEX interface |
| P1.05 | IF_SWK_CLK | nRF9160 SWD interface clock line |
| P1.06 | N.A. | Not used |
| P1.07 | COEX0 | nRF9160 COEX interface |
| P1.08 | SDA | I ² C data line |
| P1.09 | SCL | I ² C clock line |
| P1.10 | N.A. | Not used |
| P1.11 | SPARE8 | Digital <i>GPIO</i> externally available |
| P1.12 | N.A. | Not used |
| P1.13 | BOOT | Boot button |
| P1.14 | N.A. | Not used |
| P1.15 | N.A. | Not used |

Table 3: nRF52840 pin map

6.6 Motion sensors

Nordic Thingy:91 includes a low-power accelerometer and a high-G accelerometer.




Figure 18: Low-power and high-G accelerometers schematic

When Nordic Thingy:91 is in low-power sleep mode, any user interaction will be detected by the low-power accelerometer. The accelerometer has an SPI interface and it can detect motion on three axes. By default, the INT2 line of the accelerometer is not connected to nRF9160. If you want to use the INT2 line, solder **SB6**.

For detecting shocks, Nordic Thingy:91 uses a high-G accelerometer. The accelerometer has an SPI interface, and it can detect motion on three axes. By default, the INT2 line of the accelerometer is not connected to nRF9160. If you want to use the INT2 line, solder **SB5**.




Figure 19: Low-power accelerometer and high-G accelerometer interrupt line 2 selection

6.7 Environment sensors

To monitor its surroundings, Nordic Thingy:91 has a multi-sensor chip that contains several sensors for detecting different environmental properties and a separate color and light sensor.

The multi-sensor chip contains sensors for temperature, humidity, air quality, and air pressure.




Figure 20: Environment sensor schematic

The color sensor onboard Nordic Thingy:91 senses red, green, blue, and infrared light. The sensor faces towards the blue transparent bottom case with light pipes guiding the light towards the sensor. To measure the color on a surface, the color sensor is accompanied with an RGB LED that can illuminate the surface enabling the color sensor to read the color of the reflected light. The color sensor is accessed through I²C (slave address 0x38).




Figure 21: Color sensor schematic

6.8 Buzzer

For audio output, Nordic Thingy:91 has a magnetic buzzer. The buzzer is driven by a transistor using a PWM input.




Figure 22: Buzzer schematic

6.9 LEDs and buttons

Nordic Thingy:91 user interface consists of RGB LEDs and two buttons.

6.9.1 RGB LED

Nordic Thingy:91 is equipped with three RGB LEDs.

Two of the LEDs are used to light up the light well and are controlled by the same signals using transistors as switches. The third LED is located near the color sensor and is used as auxiliary light for color measurements.




Figure 23: LED schematic

6.9.2 Buttons

Nordic Thingy:91 has two buttons.

The main button, located underneath the Nordic Semiconductor logo, is termed as the **SW3** button and it is used for user input. It is connected to the nRF9160 *SiP*. The second button, termed as **SW4**, is connected to the nRF52840 *SoC*. It is accessible only when the rubber cover on the device is removed. Refer the image [Figure 4: Inserting the SIM card](#) on page 11 to locate the buttons.

Either of the two buttons, **SW3** or **SW4**, can be used to activate the serial recovery mode of Nordic Thingy:91 to update the nRF9160 *SiP* or the nRF52840 *SoC* respectively.

For more information, see [Programming applications on Nordic Thingy:91 through USB \(MCUboot\)](#).

6.10 Power supply


The main power source is a rechargeable lithium polymer (Li-Po) battery. The battery has a nominal capacity of 1400 mAh and can be recharged through *USB*.

Nordic Thingy:91 has a power switch that physically disconnects the battery and the *USB* power from the rest of the circuits. This switch must be on for Nordic Thingy:91 to work and charge the battery. When the power switch is in the OFF position, it activates a circuit that drains the 1.8 V power domain.

6.10.1 PMIC

The PMIC has three voltage domain outputs that are used on Nordic Thingy:91:

- The 3.3 V domain supplies the LEDs, the color sensor, the buzzer, the RF switches and the *GPS* LNA. This power domain can be powered down to save power when Nordic Thingy:91 is in sleep mode.



6.10.2 Current measurement



NORDIC
SEMICONDUCTOR




Figure 26: Measuring current to the nRF9160




Figure 27: Measuring current to the nRF52840




Figure 28: Current measurement schematic

6.11 Programming and debugging interface

Nordic Thingy:91 is equipped with one programming and debugging interface connector (P8) that is shared between the nRF9160 and nRF52840.

The device to be programmed is selected by the SWD SELECT switch (SW2). The selection of device can also be controlled by connecting TP28 to 1.8 V or ground.




Figure 29: SWD SELECT switch

The SWD interface of the nRF9160 can also be connected to the nRF52840. The enabling of this connection is controlled by the nRF52840.




Figure 30: SWD interface and control schematic

6.12 Interface

To enable the user to connect external hardware, Nordic Thingy:91 routes some of the *GPIOs* to connectors or test points and transistors to drive higher currents.

6.12.1 N-MOS transistors

Nordic Thingy:91 is equipped with four N-MOS transistors that can be used to drive small DC motors or LEDs. The drain and source of the transistors are available on external connectors and the gate is connected directly to the nRF9160.



In addition to the N-MOS drain and source on **P7**, power domains and extra *GPIOs* can be found on connectors **P3-P6**.

Figure 33: Interface connectors

| Pin | Signal | Description |
|-----|---------------------|-----------------|
| 1 | GND | Ground |
| 2 | V _{Li-Ion} | Battery voltage |

| Pin | Signal | Description |
|-----|--------|------------------------|
| 1 | GND | Ground |
| 2 | 1V8 | Regulated 1.8 V domain |



NORDIC
SEMICONDUCTOR

| Pin | Signal | Description |
|-----|--------|------------------------|
| 1 | GND | Ground |
| 2 | 3V3 | Regulated 3.3 V domain |

Table 6: Pinout of connector P5

| Pin | Signal | Description |
|-----|--------|----------------------|
| 1 | SPARE1 | GPIO of the nRF52840 |
| 2 | SPARE2 | GPIO of the nRF52840 |
| 3 | SPARE3 | GPIO of the nRF52840 |
| 4 | SPARE4 | GPIO of the nRF52840 |
| 5 | SPARE5 | GPIO of the nRF52840 |
| 6 | SPARE6 | GPIO of the nRF52840 |

Table 7: Pinout of connector P6

| Pin | Signal | Description |
|-----|---------|------------------------------|
| 1 | 1V8 | Regulated 1.8 V domain |
| 2 | GND | Ground |
| 3 | MOS_1_D | Drain of n-channel MOSFET 1 |
| 4 | MOS_1_S | Source of n-channel MOSFET 1 |
| 5 | MOS_2_D | Drain of n-channel MOSFET 2 |
| 6 | MOS_2_S | Source of n-channel MOSFET 2 |
| 7 | MOS_3_D | Drain of n-channel MOSFET 3 |
| 8 | MOS_3_S | Source of n-channel MOSFET 3 |
| 9 | MOS_4_D | Drain of n-channel MOSFET 4 |
| 10 | MOS_4_S | Source of n-channel MOSFET 4 |

Table 8: Pinout of connector P7

6.12.3 Test points

| Test point | Location | Signal | Description |
|------------|----------|-----------------------|---|
| TP1 | Bottom | N.A. | Reserved |
| TP2 | Bottom | RF_SW1 | Bit 0 of RF switch control signals |
| TP3 | Bottom | RF_SW2 | Bit 1 of RF switch control signals |
| TP4 | Bottom | RF_SW3 | Bit 2 of RF switch control signals |
| TP5 | Bottom | N.A. | Reserved |
| TP6 | Bottom | N.A. | Reserved |
| TP7 | Bottom | nRF91-P0.10 | <i>GPIO</i> of the nRF9160 |
| TP8 | Top | nRF52-P0.18/RESET | <i>GPIO</i> /RESET of the nRF52840 |
| TP9 | Top | SCL | I ² C clock line |
| TP10 | Top | SDA | I ² C data line |
| TP11 | Top | VBUS' | USB voltage before power switch |
| TP12 | Top | VBUS | USB voltage after power switch |
| TP13 | Top | V _{Li-Ion} ' | Battery voltage before power switch |
| TP14 | Top | V _{Li-Ion} | Battery voltage after power switch |
| TP15 | Top | GND | Ground |
| TP16 | Top | GND | Ground |
| TP17 | Top | VSYS | Internal power domain of PMIC and default nRF9160 power supply |
| TP18 | Top | 1V8 | Regulated 1.8 V domain |
| TP19 | Top | 3V3 | Regulated 3.3 V domain |
| TP20 | Bottom | ADP_PGOOD1 | PMIC output status indication pin 1 |
| TP21 | Bottom | ADP_PGOOD2 | PMIC output status indication pin 2 |
| TP22 | Bottom | ADP_STP | Stop the buck regulator switching of PMIC |
| TP23 | Bottom | ADP_RESET | PMIC reset output |
| TP24 | Bottom | ADP_MR | PMIC manual reset input |
| TP25 | Bottom | SPARE7 | <i>GPIO</i> of the nRF52840 |
| TP26 | Bottom | SPARE8 | <i>GPIO</i> of the nRF52840 |
| TP27 | Top | SWDIO | Programming interface data line |
| TP28 | Top | SWDSEL | Programming interface target select |
| TP29 | Top | SWDCLK | Programming interface clock line |
| TP30 | Top | D- | USB data line |
| TP31 | Top | D+ | USB data line |
| TP32 | Top | nRF91-P0.13/AINO | Analog/digital <i>GPIO</i> of the nRF9160, combined with N-MOS1 |

| Test point | Location | Signal | Description |
|------------|----------|------------------|---|
| TP33 | Top | nRF91-P0.16/AIN3 | Analog/digital <i>GPIO</i> of the nRF9160, combined with N-MOS4 |
| TP34 | Top | SCK | SPI clock line |
| TP35 | Top | MOSI | SPI master output, slave input data line |
| TP36 | Top | MISO | SPI master input, slave output data line |
| TP37 | Top | ADXL372_CS | High-G accelerometer chip select line |
| TP38 | Top | ADXL362_CS | Low-power accelerometer chip select line |

Table 9: Pinout of connector P3

7 Regulatory notices

The following regulatory notices apply to Nordic Thingy:91.

7.1 FCC regulatory notices

Modification statement

Nordic Semiconductor ASA has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment.

Interference statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Wireless notice

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The antenna should be installed and operated with minimum distance of 20 cm between the radiator and your body.

FCC Class B digital device notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Glossary

Development Kit (DK)

A development platform used for application development.

GPIO

General-Purpose Input/Output

Global Positioning System (GPS)

A satellite-based radio navigation system that provides its users with accurate location and time information over the globe.

Integrated Development Environment (IDE)

A software application that provides facilities for software development.

MCUboot

A secure bootloader for 32-bit microcontroller units, which is independent of hardware and operating system.

Near Field Communication (NFC)

A standards-based short-range wireless connectivity technology that enables two electronic devices to establish communication by bringing them close to each other.

Personal Unblocking Key (PUK)

A digit sequence required in 3GPP mobile phones to unlock a *SIM* that has disabled itself after an incorrect personal identification number has been entered multiple times.

Software Development Kit (SDK)

A set of tools used for developing applications for a specific device or operating system.

SEGGER Embedded Studio (SES)

A cross-platform *IDE* for embedded C/C++ programming with support for Nordic Semiconductor devices, produced by SEGGER Microcontroller.

Subscriber Identity Module (SIM)

A card used in *User Equipment (UE)* containing data for subscriber identification.

System in Package (SiP)

A number of integrated circuits, often from different technologies, enclosed in a single module that performs as a system or subsystem.

System on Chip (SoC)

A microchip that integrates all the necessary electronic circuits and components of a computer or other electronic systems on a single integrated circuit.

User Equipment (UE)

Any device used by an end-user to communicate. The UE consists of the Mobile Equipment (ME) and the Universal Integrated Circuit Card (UICC).

Universal Integrated Circuit Card (UICC)

A new generation *SIM* used in *UE* for ensuring the integrity and security of personal data.

Universal Serial Bus (USB)

An industry standard that establishes specifications for cables and connectors and protocols for connection, communication, and power supply between computers, peripheral devices, and other computers.

Acronyms and abbreviations

These acronyms and abbreviations are used in this document.

DK

Development Kit

GPIO

General-Purpose Input/Output

GPS

Global Positioning System

IDE

Integrated Development Environment

NFC

Near Field Communication

PUK

Personal Unblocking Key

SDK

Software Development Kit

SES

SEGGER Embedded Studio

SIM

Subscriber Identity Module

SiP

System in Package

SoC

System on Chip

USB

Universal Serial Bus

UICC

Universal Integrated Circuit Card

Legal notices

By using this documentation you agree to our terms and conditions of use. Nordic Semiconductor may change these terms and conditions at any time without notice.

Liability disclaimer

Nordic Semiconductor ASA reserves the right to make changes without further notice to the product to improve reliability, function, or design. Nordic Semiconductor ASA does not assume any liability arising out of the application or use of any product or circuits described herein.

Nordic Semiconductor ASA does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. If there are any discrepancies, ambiguities or conflicts in Nordic Semiconductor's documentation, the Product Specification prevails.

Nordic Semiconductor ASA reserves the right to make corrections, enhancements, and other changes to this document without notice.

Life support applications

Nordic Semiconductor products are not designed for use in life support appliances, devices, or systems where malfunction of these products can reasonably be expected to result in personal injury.

Nordic Semiconductor ASA customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify Nordic Semiconductor ASA for any damages resulting from such improper use or sale.

RoHS and REACH statement

Complete hazardous substance reports, material composition reports and latest version of Nordic's REACH statement can be found on our website www.nordicsemi.com.

Trademarks

All trademarks, service marks, trade names, product names, and logos appearing in this documentation are the property of their respective owners.

Copyright notice

© 2020 Nordic Semiconductor ASA. All rights are reserved. Reproduction in whole or in part is prohibited without the prior written permission of the copyright holder.

**COMPANY WITH
QUALITY SYSTEM
CERTIFIED BY DNV GL
= ISO 9001 =**