

Oryon Technologies, Inc.

Inverter Instructions

Button and Ports



1. Power Button
2. Recharge Port
3. Power Port
4. Identifier Label



Recharging



1. The inverter should be charged completely before the first use. The charge indicator is located beneath the Power Button and will illuminate red while charging. When charging is complete the light will go out.
2. Use the enclosed miniUSB to USB cable to recharge the inverter. After connecting the miniUSB plug into miniUSB port on the inverter, you can connect the USB plug to any computer device, wall plug or car adapter that has a USB port.
3. Complete charging time is typically 6 to 7 hours.

Operation



1. Locate the connector in the garment and insert the plug into the power port of the inverter.
2. Make sure the connector color from the garment matches the color code on the inverter label.
3. Press the Power Button for 1 second and the lights will begin to flash.
4. Pressing the Power Button again for 1 second and the lights will flash at a faster rate.
5. Pressing the Power Button again for 1 second and the lights will remain steady on.
6. Pressing the Power Button again for 1 second and the lights will turn off.

IMPORTANT

Prior to washing, unplug the garment from the inverter and remove the inverter from the garment